

## **EXPRO National Manual for Projects Management**

Volume 11, Chapter 2

**Supervisor Safety Pocket Book** 



Doc. No. EPM-KS0-MN-000002 Rev 001



## **Supervisor Safety Pocket Book**

## **SUPERVISOR Fire Prevention and Protection Barricades and Signs Inspection Program SAFETY** Dangerous areas marked with red/black danger tape. Separate fuel cylinders from oxidizers by at least 6m or by a 1-hour fire wall while in storage. → Inspect fire extinguishers in the following: When any hot work is being completed → Caution areas marked with yellow/black barrier Never transport acetylene or liquid fuel containers on their side. Before each use On a monthly basis **BOOK** Remove gauges and reinstall caps after use or at the end of each shift. → Barricade tape must be on all sides without gaps. -> Perform and log quarterly inspections on the Use hard (rigid) barricades in areas where work will continue more than 24 hours. → Use metal safety cans when transporting or Ladders - portable and fixed Ensure all protective barricades are capable of supporting 90(kg) of force. de-canting. Fall protection - harnesses and lanyards → Ensure metal storage cabinets are used. Electrical equipment - tools and connections → Ensure hot work permit is in place when cutting. Rigging and lifting - equipment and hardware brazing, or welding. → Fire watch in place when completing Hot Work. Imminently Dangerous Areas Authorized Personnel Only



## **Supervisor Safety Pocket Book**

